



Anslutningar:

1. [1" utv] Expansion/avlufning
2. [DN32] Tillopp värmepanna alt till extra tank
3. [DN20] Termometer
4. [DN50] Elpatronuttag
5. [DN32] Retur till värmepanna
6. [DN20] Avtappning
7. [DN50] Anslutning för BoRö Shuntpaket

Utrustning:

A. [Ø22] Förrädsberedare 110 lit. koppar

